

OMP Suit Sizing

Size	42	44	46	48	50	52	54	56	58	60	62	64
	X-Small	X-Small	Small	Small	Medium	Medium	Large	Large	X-Large	X-Large	XX-Large	XX-Large
Chest	31 - 33	33 - 35	36 - 37	37 - 39	39 - 40	41 - 42	42 - 43	44 - 45	45 - 47	47 - 48	48 - 50	50 - 51
Waist	25 - 27	27 - 28	28 - 30	30 - 31	31 - 33	33 - 35	35 - 36	37 - 38	38 - 39	39 - 41	41 - 43	43 - 45
Hips	32 - 34	34 - 35	36 - 37	37 - 39	39 - 40	41 - 42	42 - 43	44 - 45	45 - 47	47 - 48	48 - 50	50 - 51
Shoulders	14 - 16	15 - 16	15 - 17	16 - 18	17 - 19	18 - 20	18 - 20	18 - 21	19 - 20	19 - 21	19 - 22	20 - 22
Sleeve	23 - 24	23 - 24	24 - 25	24 - 25	25 - 26	25 - 27	26 - 28	27 - 28	28 - 29	28 - 30	28 - 30	28 - 30
Inseam	27 - 28	28 - 29	28 - 30	29 - 31	30 - 32	31 - 32	32 - 33	32 - 34	33 - 35	34 - 35	34 - 35	34 - 36
Back	16 - 18	17 - 19	18 - 19	18 - 20	19 - 20	19 - 21	19 - 20	19 - 21	19 - 22	20 - 22	20 - 22	21 - 23
Height	4'11" - 5'2"	5'1" - 5'5"	5'2" - 5'6"	5'4" - 5'7"	5'5" - 5'9"	5'6" - 5'11"	5'8" - 6'1"	5'9" - 6'2"	6'0" - 6'4"	6'1" - 6'5"	6'2" - 6'5"	6'3" - 6'6"

All measurements in inches unless otherwise indicated. Please see diagram below for sizing help.

Sizing Tips: A Driving Suit should have a loose, comfortable fit and allow for a full range of motion. Make sure the fit doesn't change when sitting down!

A suit that fits tightly may sacrifice the protective layer of air between the suit and your skin/underwear and can potentially decrease the level of protection provided by your suit.

Driving suits do not "break-in" or stretch over time.